

HP CARTRIDGE REFERENCE

HP DESKJET PRINTER

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP DJ D1360	C9351AA	C9352AA	
HP DJ D1368	C8816AA	C8817AA	
HP DJ D2360	C9351AA	C9352AA	
HP DJ D2368	C8816AA	C8817AA	
HP DJ D4160	C9364WA	C9361AA	
HP DJ D4168	C9364ZZ	C9361ZZ	
HP DJ 400, 420c	51626AA	51625AA	
HP DJ 500	51626AA		
HP DJ 500c	51626AA	51625AA	
HP DJ 520	51626AA		
HP DJ 540, 550c, 560c	51626AA	51625AA	
HP DJ 600	51629AA	51649AA	
HP DJ 610c, 630c, 640c, 656c	C6614DA	51649AA	
HP DJ 660c, 670c	51629AA	51649AA	
HP DJ 690c, 692c, 694c, 695c	51629AA	51649AA	C1816AA
HP DJ 710c, 720c	51645AA	C1823DA	
HP DJ 810c	C6615DA	C1823DA	
HP DJ 820cxi	51645AA	51641AA	
HP DJ 830c	51645AA	C1823DA	
HP DJ 840c, 845c	C6615DA	C6625AA	
HP DJ 850c, 870cxi	51645AA	51641AA	
HP DH 880c, 890c, 895cxi	51645AA	C1823DA	
HP DJ 920c	C6615DA	C6578A	
HP DJ 930c	51645AA	C6578A	
HP DJ 948c	C6615DA	C6625AA	
HP DJ 950c, 960c	51645AA	C6578A	
HP DJ 970cxi, 990cxi	51645AA	C6578A	
HP DJ 1000cxi	51645AA	51641AA	
HP DJ 1120c, 1125c	51645AA	C1823DA	
HP DJ 1180c	51645AA	C6578A	
HP DJ 1200c, 1200c/ps	51640C		
HP DJ 1220c	51645AA	C6578A	
HP DJ 1280	51645AA	C6578A	
HP DJ 1600c, 1600cxi	51645AA		51640C
HP DJ 3320	C8727AA	C8728AA	
HP DJ 3325	C8727AA	C8728AA	
HP DJ 3420	C8727AA	C8728AA	
HP DJ 3535	C8727AA	C8728AA	
HP DJ 3538	C8816AA	C8817AA	
HP DJ 3550	C8727AA	C8728AA	
HP DJ 3558	C8816AA	C8817AA	
HP DJ 3650	C8727AA	C8728AA	
HP DJ 3658, 3668	C8816AA	C8817AA	
HP DJ 34743	C8816AA	C8817AA	
HP DJ 3744	C8727AA	C8728AA	
HP DJ 3745	C8727AA	C8728AA	

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP DJ 3748	C8816AA	C8817AA	
HP DJ 3820	C6615DA	C6578A	
HP DJ 3845	C8727AA	C8728AA	
HP DJ 3848	C8816AA	C8817AA	
HP DJ 3918	C8816AA	C8817AA	
HP DJ 3920	C9351AA	C9352AA	
HP DJ 5160	C6656AA	C6657AA	
HP DJ 5168	C8816AA	C8817AA	
HP DJ 5438	C9362ZZ	C9361ZZ	
HP DJ 5440	C9362WA	C9361ZZ	
HP DJ 5550	C6656AA	C6657AA	
HP DJ 5650	C6656AA	C6657AA	
HP DJ 5652	C6656AA	C6657AA	
HP DJ 5740	C8765WA	C8766WA	
HP DJ 5748	C8765ZZ	C8766ZZ	
HP DJ 6122	51645AA	C6578A	
HP DJ 6540	C8767WA	C9363WA	
HP DJ 6548, 6848	C8767ZZ	C9363ZZ	
HP DJ 6840	C8767WA	C9363WA	
HP DJ 9300	51645AA	C6578A	
HP DJ 9600	C6656AA	C6657AA	
HP DJ 9650	C6656AA	C6657AA	
HP DJ 9680	C6656AA	C6657AA	
HP DJ 9800	C8767WA	C9363WA	
HP DJ 9808	C8767ZZ	C9363ZZ	
HP DJ 9860	C8767WA	C9363WA	
HP DJ 9868	C8767ZZ	C9363ZZ	
HP DJ PLUS	51626AA		
HP DJ DESKWRITER	51626AA		
HP DJ DESKWRITER C	51626AA	51625AA	
HP DJ DESKWRITER 320	51633MA	51625AA	
HP DJ DESKWRITER 520	51626AA		
HP DJ DESKWRITER 540	51626AA	51625AA	
HP DJ DESKWRITER 550c	51626AA	51625AA	
HP DJ DESKWRITER 560c	51626AA	51625AA	
HP Deskjet All-in-One			
HP DJ F370	C9351AA	C9352AA	
HP DJ F378	C8816AA	C8817AA	
HP DJ F380	C9351AA	C9352AA	
HP DJ F388	C8816AA	C8817AA	
HP Deskjet Mobile Printer			
HP DJ 320, 340	51633MA	51625AA	
HP DJ 330, Portable	51633MA		
HP DJ 350cbi	C6628AA	51649AA	
HP DJ 450ci/cbi/wbi	C6656AA	C6657AA	

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP Deskjet Mobile Printer (Contd.)			
HP DJ 460	C8765WA	C8766WA	
HP DJ 460	C8765ZZ	C8766ZZ	
HP Photosmart Printer			
HP Photosmart D5160	C9364WA	C8766WA	
HP Photosmart D5168	C9364ZZ	C8766ZZ	
HP Photosmart P1000, P1100	51645AA	C6578A	
HP Photosmart P1215, P1218	51645AA	C6578A	
HP Photosmart 7150	C6656AA	C6657AA	
HP Photosmart 7260		C6657AA	C6658AA
HP Photosmart 7268		C6657AA	C6658AA
HP Photosmart 7450		C6657AA	C6658AA
HP Photosmart 7458	C8816AA	C8817AA	
HP Photosmart 7550	C6656AA	C6657AA	
HP Photosmart 7660		C6657AA	C6658AA
HP Photosmart 7760		C6657AA	C6658AA
HP Photosmart 7830	C9362WA	C8766WA	
HP Photosmart 7838	C9362ZZ	C8766ZZ	
HP Photosmart 7960		C6657AA	C6658AA
HP Photosmart 8030	C9364WA	C8766WA	
HP Photosmart 8038	C9364ZZ	C8766ZZ	
HP Photosmart 8150		C8766WA	C9369WA
HP Photosmart 8158		C8766ZZ	C9369ZZ
HP Photosmart 8450		C9363WA	C9369WA
HP Photosmart 8458		C9369ZZ	C9369ZZ
HP Photosmart 8750		C9363WA	C9365AA
HP Photosmart 8758		C9363ZZ	C9365AA
HP Photosmart All-in-One			
HP Photosmart C3180	C9362WA	C9361AA	
HP Photosmart C3188	C9362ZZ	C9361ZZ	
HP Photosmart C4180	C9364WA	C9361AA	
HP Photosmart C4188	C9364ZZ	C9361ZZ	
HP Photosmart 2410	C6656AA	C6657AA	
HP Photosmart 2510	C6656AA	C6657AA	
HP Photosmart 2575	C9364WA	C8766WA	
HP Photosmart 2578	C9364ZZ	C8766ZZ	
HP Photosmart 2608	C8767ZZ	C9363ZZ	
HP Photosmart 2610	C8767WA	C9363WA	
HP Photosmart 2710	C8767WA	C9363WA	
HP PSC 500	C6615DA	C1823DA	
HP PSC 750	C6615DA	C6578A	
HP PSC 950	C6615DA	C6578A	
HP PSC 1110	C6656AA	C6657AA	
HP PSC 1118	C8816AA	C8817AA	
HP PSC 1210	C8727AA	C8728AA	

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP PSC 1218	C8816AA	C8817AA	
HP PSC 1315	C8727AA	C8728AA	
HP PSC 1318	C8816AA	C8817AA	
HP PSC 1350	C6656AA	C6657AA	
HP PSC 1402, 1410	C9351AA	C9352AA	
HP PSC 1406	C8816AA	C8817AA	
HP PSC 1406	C9351AA	C9352AA	
HP PSC 1408	C8816AA	C8817AA	
HP PSC 1408	C9351AA	C8817AA	
HP PSC 1410	C9351AA	C9352AA	
HP PSC 1508	C9362ZZ	C9361ZZ	
HP PSC 1510	C9362WA	C9361AA	
HP PSC 1608	C8765ZZ	C8766ZZ	
HP PSC 1610	C8765WA	C8766WA	
HP PSC 2110	C6656AA	C6657AA	
HP PSC 2210	C6656AA	C6657AA	
HP PSC 2310	C6656AA	C6657AA	
HP PSC 2355	C8765WA	C9363WA	
HP PSC 2358	C8765ZZ	C9363ZZ	
HP Photosmart Pro Photo Printer			
HP Photosmart Pro 88330		C9363WA	C9369WA
HP Photosmart Pro 88338		C9363ZZ	C9369ZZ
HP Photosmart Compact Photo Printer			
HP Photosmart A310		C8304AA	
HP Photosmart A516		C8304AA	
HP Photosmart A616		C8304AA	
HP Photosmart A716		C8304AA	
HP Photosmart 130		C6657AA	
HP Photosmart 145		C6657AA	
HP Photosmart 148		C8817AA	
HP Photosmart 245		C6657AA	
HP Photosmart 325		C8766WA	
HP Photosmart 325		C8766ZZ	
HP Photosmart 335		C8766WA	
HP Photosmart 335		C8766ZZ	
HP Photosmart 375		C8766WA	
HP Photosmart 375		C8766ZZ	
HP Photosmart 385		C8766WA	
HP Photosmart 385		C8766ZZ	
HP Photosmart 425		C8766WA	
HP Photosmart 425		C8766ZZ	
HP Photosmart 475		C9363WA	
HP Photosmart 475		C9363ZZ	

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP Officejet All-in-One			
HP D145, D155	C5011A	C4920A	
HP Officejet G55, G85	51645AA	C6578A	
HP Officejet G95	51645AA	C6578A	
HP Officejet K60, K80	51645AA	C6878A	
HP Officejet LX	51626AA		
HP Officejet r45, r65	51645AA	C1823DA	
HP Officejet t45, t65	51645AA	C1823DA	
HP Officejet v40	C6615DA	C6578A	
HP Officejet 300, 330, 350	51626AA		
HP Officejet 590	51629AA	51649AA	
HP Officejet 630, 635	51629AA	51649AA	
HP Officejet 710, 725	51629AA	51649AA	C1816AA
HP Officejet 4110	C6656AA	C8728AA	
HP Officejet 4255	C6656AA	C8728AA	
HP Officejet 4308	C8816AA	C8817AA	
HP Officejet 4338	C8816AA	C8817AA	
HP Officejet 4355	C9351AA	C9352AA	
HP Officejet 5110	C6615DA	C6878A	
HP Officejet 5510	C6656AA	C6657AA	
HP Officejet 5608	C8816AA	C8817AA	
HP Officejet 5610	C8727AA	C9352AA	
HP Officejet 5679	C8727AA	C8728AA	
HP Officejet 5680	C8727AA	C9352AA	
HP Officejet 6110	C6656AA	C6657AA	
HP Officejet 6208	C8765ZZ	C8766ZZ	
HP Officejet 6210	C8765WA	C8766WA	
HP Officejet 7310	C9364WA	C9361AA	
HP Officejet 6318	C9364ZZ	C9361ZZ	
HP Officejet 7130	C5011A	C4920A	
HP Officejet 7140	C5011A	C4920A	
HP Officejet 7208	C8767ZZ	C9363ZZ	
HP Officejet 7210	C8767WA	C9363WA	
HP Officejet 7408	C8767ZZ	C9363ZZ	
HP Officejet 7410	C8767WA	C9363WA	
HP Officejet 9110	C4800A		
HP Officejet 9120	C4800A		
HP Officejet 9130	C4800A		
HP Officejet Pro Colour Printer			
HP Officejet Pro K550/K550dtn	C9391A		
HP Officejet Pro K850/K850dtn	C4814A		
HP Officejet All-in-One			
HP Officejet Pro 1150c	51645AA	51641AA	
HP Officejet Pro 1170c	51645AA	C1823DA	
HP Officejet Pro 1175c	51645AA	C1823DA	

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP Business Inkjet Printer			
HP Business Inkjet cp1160	C5011A	C4920A	
HP Colour Inkjet cp1700, cp1700d	C4800A		
HP Business Inkjet 1000	C4814A		
HP Business Inkjet 1100, 1100dtn	C4800A		
HP Business Inkjet 1200, 1200d	C4800A		
HP Business Inkjet 1200dtn, 1200dtwn	C4800A		
HP Business Inkjet 2000c, 2000cn	C4800A		
HP Business Inkjet 2230, 2280, 2280tn	C4800A		
HP Business Inkjet 2300, 2300dtn	C4800A		
HP Business Inkjet 2500c, 2500cm	C4800A		
HP Business Inkjet 2600, 2600dn	C4800A		
HP Business Inkjet 2800, 2800dn	C4800A		
HP Business Inkjet 3000, 3000n, 3000dtn	C4800A		
HP COLOUR LASERJET PRINTER			
Colour Laserjet 1500/2500 Printer Series			
Black	C9700A		
Cyan	C9701A		
Yellow	C9702A		
Magenta	C9703A		
Imaging Drum	C9704A		
Colour Laserjet 2550 Printer Series			
Black	Q3960A		
Cyan	Q3961A		
Yellow	Q3962A		
Magenta	Q3963A		
Cyan	Q3971A		
Yellow	Q3972A		
Magenta	Q3973A		
Imaging Drum	Q3964A		
Colour Laserjet 1600/2600n Printer Series			
Black	Q6000A		
Cyan	Q6001A		
Yellow	Q6002A		
Magenta	Q6003A		
Colour Laserjet 2605 Printer Series			
Black	Q6000A		
Cyan	Q6001A		
Yellow	Q6002A		
Magenta	Q6003A		
Colour Laserjet 2700 Printer Series			
Black	Q7560A		
Cyan	Q7561A		
Yellow	Q7562A		
Magenta	Q7563A		

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP Colour Laserjet Printer			
Colour Laserjet 3000 Printer Series			
Black	Q7560A		
Cyan	Q7561A		
Yellow	Q7562A		
Magenta	Q7563A		
Colour Laserjet 3500/3550 Printer Series			
Black	Q2670A		
Cyan	Q2671A		
Yellow	Q2672A		
Magenta	Q2673A		
Colour Laserjet 3600 Printer Series			
Black	Q6470A		
Cyan	Q6001A		
Yellow	Q6002A		
Magenta	Q6003A		
Colour Laserjet 3700 Printer Series			
Black	Q2670A		
Cyan	Q2681A		
Yellow	Q2682A		
Magenta	Q2683A		
Colour Laserjet 3800 printer series			
Black	Q6470A		
Cyan	Q7581A		
Yellow	Q7582A		
Magenta	Q7583A		
Colour Laserjet 4500/4550 printer series			
Black	C4191A		
Cyan	C4192A		
Yellow	C4193A		
Magenta	C4194A		
Drum Kit	C4195A		
Transfer Kit	C4196A		
Fuser Kit	C4197A		
Fuser Kit	C4198A		
Colour Laserjet 4600/4650 printer series			
Black	C9720A		
Cyan	C9721A		
Yellow	C9722A		
Magenta	C9723A		
Colour Laserjet 4700 printer series			
Black	Q5950A		
Cyan	Q5951A		
Yellow	Q5952A		
Magenta	Q5953A		

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP Colour Laserjet Printer			
Colour Laserjet 5500/5550 printer series			
Black	C9730A		
Cyan	C9731A		
Yellow	C9732A		
Magenta	C9733A		
Colour Laserjet 8500/8550 printer series			
Black	C4149A		
Cyan	C4150A		
Yellow	C4151A		
Magenta	C4152A		
Drum Kit	C4153A		
Transfer Kit	C4154A		
Fuser Kit	C4155A		
Fuser Kit	C4156A		
Colour Laserjet 9500 printer series			
Black	C8550A		
Cyan	C8551A		
Yellow	C8552A		
Magenta	C8553A		
Cleaning Kit	C8554A		
Transfer Kit	C8555A		
Fuser Kit	C8556A		
Black Imaging Kit	C8560A		
Cyan	C8561A		
Yellow	C8562A		
Magenta	C8563A		
Black	Q5920C		
Cyan	Q5921C		
Yellow	Q5922C		
Magenta	Q5923C		
HP Colour Laserjet All-in-One			
Colopur Laserjet 2820/2840 All-in-One			
Black	Q3960A		
Cyan	Q3961A		
Yellow	Q3962A		
Magenta	Q3963A		
Cyan	Q3971A		
Yellow	Q3972A		
Magenta	Q3973A		
Imaging Drum	Q3964A		
Colour Laserjet CM1015MFP			
Black	Q6000A		
Cyan	Q6001A		
Yellow	Q6002A		
Magenta	Q6003A		

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
Colour Laserjet CM1017 MFP			
Black	Q6000A		
Cyan	Q6001A		
Yellow	Q6002A		
Magenta	Q6003A		
Colour Laserjet 4730mfp series			
Black	Q6460A		
Cyan	Q6461A		
Yellow	Q6462A		
Magenta	Q6463A		
Colour Laserjet 9500mfp			
Black	C8550A		
Cyan	C8551A		
Yellow	C8552A		
Magenta	C8553A		
Cleaning Kit	C8554A		
Transfer Kit	C8555A		
Fuser Kit	C8556A		
Black Imaging Drum	C8560A		
Cyan	C8561A		
Yellow	C8562A		
Magenta	C8553A		
Colour 9850mfp			
Black	Q5920C		
Cyan	Q5921C		
Yellow	Q5922C		
Magenta	Q5923C		
HP Monochrome Laserjet Printers			
Laserjet P2015 printer series	Q7553A/X		
Laserjet P3005 printer series	Q7551A/X		
Laserjet 41/4ml/4p/4mp Printer	92274A		
Laserjet 4/4m/4 plus/4m plus printer	92298A/X		
Laserjet 4v/4mv printer	C3900A		
Laserjet 51 printer series	C3906A/F		
Laserjet 5p/5mp Printer	C3903A/F		
Laserjet 5/5m/5n Printer	92298A/X		
Laserjet 5si/5si mx/5sc nx/5si mopier	C3909A/X		
Laserjet 61 printer series	C3903A/F		
Laserjet 1000 printer	C7115A/X		
Laserjet 1010/1012/1016 printer	Q2612A		
Laserjet 1018 Printer	Q2612A		
Laserjet 1020 Printer	Q2612A		
Laserjet 1022 Printer	Q2612A		
Laserjet 1100 Printer	C4092A		
Laserjet 1150 Printer	Q2624A		

Printer Model	CARTRIDGE REFERENCE NUMBER		
	Black	Colour	Photo
HP Monochrome Laserjet Printers			
Laserjet 1160 Printer	Q5949A		
Laserjet 1200 printer series	C7115A/X		
Laserjet 1300 printer series	Q2613A/X		
Laserjet 1320 printer series	Q5949A/X		
Laserjet 2100/2200 printer series	C4096A		
Laserjet 2300 printer series	Q2610A		
Laserjet 2400 printer series	Q6511A/X		
Laserjet 4000/4050 printer series	C4127A/X		
Laserjet 4200 printer serues	Q1338A		
Laserjet 4250 printer series	Q5942A/X		
Laserjet 4300 printer series	Q1339A		
Laserjet 4350 printer series	Q5942A?X		
Laserjet 5000/5100 printer series	C4129X		
Laserjet 5200 printer series	Q7516A/X		
Laserjet 8000 printer series	C3909A/X		
Laserjet 8100/8150 printer series	C4182X		
Laserjet 9000 printer series	C8543X		
Laserjet 3015/3020/3030 All-in-One	Q2612A		
HP Monochrome Laserjet All-inOne			
Laserjet 3050/3052/3055 All-in-One	Q2612A		
Laserjet 3050z All-in-One	Q2612A		
Laserjet 3100 All-in-One series	C3906A/F		
Laserjet 3200 All-in-One	C4092A		
Laserjet 3300mfp series	C7115A/X		
Laserjet 3390/3392 All-in-One	Q5949A/X		
HP Monochrome Laserjet MFP			
Laserjet M3027 MFP series	Q7551A/51X		
Laserjet M3035 MFP Series	Q7551A/51X		
Laserjet M5025 MFP Series	Q7570A		
Laserjet M5035 MFP Series	Q7570A		
Laserjet 4100/4101mfp printer series	C8061A/X		
Laserjet 4345 MFP series	Q5945A		
Laserjet 9055/9065mfp	Q3683A		
Laserjet 9085mfp series	Q5703C		